

CODIGOS AVERIA ASDG24AYR - ASDG24AYR(5)

F6	FALLO MOTO VENTILADOR INTERIOR ò COTROL Comprobar cables de conexión, condensador, ficheros, bobinas y tension de salida de placa PCB. NOTA: Si la placa (PCB) no tiene 220v de salida al moto ventilador tambien indica el codigo F6
F7	FALLO EN SENSOR DE TEMPERATURA (Ambiente) UNIDAD INTERIOR Comprobar cables de conexión, ficheros, valor resistivo a 25°C 5K
F8	FALLO EN SENSOR DE BATERIA (Tubo) UNIDAD INTERIOR Comprobar cables de conexión, ficheros, valor resistivo a 25°C 5K
F9	FALLO EN SENSOR DE BATERIA (Tubo) UNIDAD EXTERIOR Comprobar cables de conexión, ficheros, valor resistivo a 25°C 5K

■ SELF DIAGNOSIS FUNCTION

Our company provides the end-users with thoughtful services by installing various diagnostic systems to indicate the following irregular performances.

Check code	Diagnosis of malfunction
FAULT F6	PG motor faults
FAULT F7	Indoor TEMP sensor faults
FAULT F8	Indoor coil pipe TEMP sensor faults
FAULT F9	Outdoor coil pipe TEMP sensor faults

